Архангельск (8182)63-90-72 Астана (7172)727-132 Астрахань (8512)99-46-04 Барнаул (3852)73-04-60 Белгород (4722)40-23-64 Брянск (4832)59-03-52 Владивосток (423)249-28-31 Волгоград (844)278-03-48 Вологда (8172)26-41-59 Воронеж (473)204-51-73 Екатеринбург (343)384-55-89 Иваново (4932)77-34-06 Ижевск (3412)26-03-58 Казань (843)206-01-48 Калининград (4012)72-03-81 Калуга (4842)92-23-67 Кемерово (3842)65-04-62 Киров (8332)68-02-04 Краснодара (861)203-40-90 Красноярок (391)204-63-61 Курск (4712)77-13-04 Липецк (4742)52-20-81 Магнитогорск (3519)55-03-13 Москва (495)268-04-70 Мурманск (8152)59-64-93 Набережные Челны (8552)20-53-41 Нижний Новтород (831)429-08-12 Новокузнецк (3843)20-46-81 Новосибирск (383)227-86-73 Омск (3812)21-46-40 Оренбург (352)37-68-04 Пенза (8412)22-31-16 Пермь (342)205-81-47 Ростов-на-Дону (863)308-18-15 Рязань (4912)46-61-64 Самара (846)206-03-16 Санкт-Петербург (812)309-46-40 Саратов (845)249-38-78 Севастополь (8692)22-31-93 Симферополь (3652)67-13-56 Смоленск (4812)29-41-54 Сочи (862)225-72-31 Ставрополь (8652)20-65-13 Сургут (3462)77-98-35 Тверь (4822)63-31-35 Томск (3822)98-41-53 Тула (4872)74-02-29 Тюмень (3452)66-21-18 Ульяновск (8422)24-23-59 Уфа (347)229-48-12 Хабаровск (4212)92-98-04 Челябинск (351)202-03-61 Череповец (8202)49-02-64 Ярославль (4852)69-52-93

Единый адрес: ath@nt-rt.ru | http://albright.nt-rt.ru

The Reduced Silver series are suitable for applications where infrequent switching is specified. In such applications the degradation of the tip is minimal and therefore a higher volume of silver is unnecessary. The RW400 has been designed by Albright for use in telecommunication and power ntly switched. These contactors are primarily for use e used with Alternating Currents.


-	400A	_		
ntermittent Current Rating:		4		
30% Duty				
	730A			
40% Duty	630A			
50% Duty	565A	_		
60% Duty	515A	4		
70% Duty	480A			
Rated Fault Current Breaking Capac (in accordance with UL508*)	ity (^I cn) Resistive Load:			
RW400	600A at 60V D.C.			
Maximum Recommended Contact Vo	oltages (U _e):			
RW400	60V D.C.	1		
Typical Voltage Drop per pole across New Contacts at 400A	< 50mV			
Mechanical M.T.B.F	>1 x 10 ⁶	_		
Coil Voltage Available (U _S) (Rectifier board required for A.C.)	From 6 to 240V A.C./D.C.	4		
Coil Power Dissipation:				
Highly Intermittent Rated Types	40 - 50 Watts	4		
ntermittently Rated Types	30 - 40 Watts	4		
Prolonged Rated Types	15 - 30 Watts	4		
Continuously Rated Types	10 - 15 Watts	4		
Maximum Pull-In Voltage (Coil at 20° C) Guideline:				
Highly Intermittent Rated types (Max 25% Duty Cycle)	60% U _S	_		
Intermittently Rated types (Max 70% Duty Cycle)	60% U _S	4		
Prolonged Operation (Max 90% Duty Cycle)	60% U _S	4		
Continuously Rated Types (100% Duty Cycle)	66% U _S			
Drop-Out Voltage Range	10 - 30% U _S	4		
Typical Pull-In Time	15ms	4		
Typical Drop-Out Time (N/O Contacts				
Without Suppression	6ms	4		
With Diode Suppression	35ms	4		
Nith Diode and Resistor (Subject to resistance value)	20ms	4		
Typical Contact Bounce Period	< 5ms	4		
Operating Ambient Temperature	- 40°C to + 60°C	4		
Guideline Contactor Weight:				
RW400	880 gms	4		
With Auxiliary	+ 20 gms	1		
Auxiliary D Auxiliary Thermal Current Rating	Details 5A			
Auxiliary Contact Switching Capal				
RW400C	RW400A			
5A at 24V				
2A at 48V				
1.3A at 72\		4		
Advised Connection Sizes for Max	imum Continuous Current			
Copper busbar 258mm² [0.39inch²]				

Key: = Uninterrupted


Note: Where applicable values shown are at 20°C * Please check our web site for product UL status


Uninterrupted current - no or infrequent load switching requirements (maintains a lower contact resistance).

The RW400 features double breaking main contacts with silver alloy tips which are weld resistant, hard wearing and have excellent conductivity. Silver plating on the main contacts is optional for the RW400. The RW400 is a compact contactor which can be busbar mounted vertically or horizontally, however if mounted vertically, the coil should be at the bottom. If the coil is required at the top, we can adjust the contactor to compensate for this.



RW400





Magnetic Blowouts - High Powere			
Armature Cap			
Mounting Brackets (see Busbar Series Catalogue)			
Magnetic Latching† (Not fail safe)			
Closed Contact Housing			
Environmentally Protected IP66			
EE Type (Steel Shroud)			
Contacts			
Contacts			
Textured Tips			
Textured Tips			
Textured Tips Silver Plating			
Textured Tips Silver Plating Coil			
Textured Tips Silver Plating Coll AC Rectifier Board (Fitted)			
Textured Tips Silver Plating Coil AC Rectifier Board (Fitted) Coil Suppression [†]			
Textured Tips Silver Plating Coil AC Rectifier Board (Fitted) Coil Suppression [†] Flying Leads			

Auxiliary Contacts

Magnetic Blowouts†

Auxiliary Contacts - V3

act Performance Key:	Connection Diagrams		
- Uninterrupted Current	RW400C	RW400A	
	AUXILIARY CONTACT	AUXILIARY CONTACT	
	2 4	NO N'C N'C N'	
	-0 0-	-0 0-	
	└	4	

Environmentally Protected IP66	X					
EE Type (Steel Shroud)	X					
Contacts						
Textured Tips	0	T				
Silver Plating	0					
Coil						
AC Rectifier Board (Fitted)	0					
Coil Suppression [†]	0					
Flying Leads	0	F				
Manual Override Operation	0					
M4 Stud Terminals	X					
M5 Terminal Board	0					
Vacuum Impregnation	0					
Key: Optional ○ Standard • 1	Not Availat	ole X				
† Connections become polarity sensitive						

RW400 Available Options

the

С

0

Х Х

Χ

0

0